

CEMENTO BLANCO

HIGH
RESISTANCE

Bathroom and kitchen repairs.

Tile, bathroom fitting and plumbing fixing.

Join finishing between walls and floors.



Description and uses of the product

Prepared hydraulic binder of excellent whiteness and high strength, ready to mix with aggregates of different granulometry and nature (limestone, siliceous, dolomite, etc.), and perform different types of masonry mortar (masonry works, masonry in general, plasters, etc.).

"Excellent Whiteness"

How to use

1. Prepare and clean substrate.
2. Water to add 0.500 litres / 1.5 kg bag
3. Manual application.

Recommendations

Application temperature +5 °C to +30 °C.

Wet the supports before applying the product.

All supports must be resistant and be clean.

On very absorbent or disintegrable supports the application of the consolidant of surfaces: **GECOL Primer-TP** 1:2 diluted in water.

Its applications are extended to:

- Repairs in bathrooms and kitchens.
- Realization of grouts in pavements and ceramic coatings, stone material and swimming pools.
- Fixation of toilets and plumbing.
- Placement of platelets, tiles and terraces.
- Completion in joints between walls and floors.
- Floors and base for pavements.
- Repairs on concrete, stone or brick.

It can be used interchangeably indoors and outdoors.

4. Setting time 3 hours.
5. Clean tools with water.

Features

Colour: White.

Compression resistance: > 42.5 N/mm²
Shelf life 12 months if sheltered.

Yield

It varies according to the type of application.

Theoretical consumption: 1,2 kg /m² per mm of thickness.

Presentation and delivery

1,5 kg bucket: 1.5 kg polypropylene bag in a plastic mixing bowl.

4,5 kg bucket: 3 polypropylene bags of 1.5 kg (3 x 1.5 kg) in plastic mixing bowl

Safety data



GHS07

Hazard statements

- H315** Causes skin irritation.
- H318** Causes serious eye damage.
- H317** May cause an allergic skin reaction.
- H335** May cause respiratory irritation.

Precautionary statements

- P261** Avoid breathing dust/fume/ gas/mist/vapours/spray.
- P280** Wear protective gloves/protective clothing

/eye protection /face protection.

P302 + P352 IN CASE OF SKIN CONTACT:
Wash with plenty of soap and water.

P305 + P351 + P338 IN CASE OF EYES CONTACT:
Rinse cautiously with water for several minutes.
Remove contact lenses, if present and easy to do.
Continue rinsing.

P310 Immediately call a POISON CENTER/doctor
1999/45/CE The product contains a chromium VI reducing agent;
the period of declared efficiency is that indicated on the packaging.