



MORTELAN Mortero de albañilería

- **Masonry mortar in general.**
- **Ready to use for plastering and plastering.**
- **All types of brick partition, concrete block and stone.**

Description and uses of the product

Dry mortar of cement and siliceous aggregates of first quality, prepared for its use.

Suitable for all types of general masonry works: masonry, plaster, assembly and assembly of cement blocks or ceramic bricks, creation of screeds and screeds, making high strength anchors, etc.

Being a product previously prepared and dosed, avoid mixing cement with sand and possible errors as a result of these. You only need to add the corresponding water.

Of great plasticity, very easy application and workability.

It can be used interchangeably indoors and outdoors.

How to use

- 1) Prepare and clean substrate.
- 2) Water to add 0,500 litres / 2 kg bag
- 3) Manual application.
- 4) Mixture workable for 90 minutes.
- 5) Clean tools with water.

Recommendations:

Application temperature + 5°C to + 30°C

Apply with a float or trowel.

Do not use on gypsum, paint or degradable product bonds.

Do not mix the product again once it begins to set.

Avoid using excessive amounts of water.

Features

Dry mortar type M80^a.

Color grey.

Resistance to compression: > 8 N / mm².

Shelf life 12 months if sheltered.

Yield

It varies according to the type of application.

Theoretical consumption 1.5 kg / m² per mm of thickness.



MORTELAN Mortero de albañilería

Presentation and delivery

2 kg inner polypropylene bag in plastic bucket and pallet with 160 buckets (320 kg).

6 kg (3 x 2 kg) inner polypropylene bag in plastic bucket and pallet with 105 buckets (630 kg).

Precautionary statements



Danger

Hazard statements

H315: Causes skin irritation

H318: Causes serious eye damage

H317: May cause an allergic skin reaction

H335: May cause respiratory irritation

Precautionary statements

P261: Avoid breathing dust/fume/ gas/mist/vapours/spray.

P280: Wear protective gloves/protective clothing/eye protection/face protection.

P302 + P352 – IN CASE OF SKIN CONTACT: Wash with plenty of soap and water.

P305 + P351 + P338 – IN CASE OF EYES CONTACT: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing.

P310: Immediately call a POISON CENTER/doctor

1999/45/CE The product contains a chromium VI reducing agent; the period of declared efficiency is that indicated on the packaging.